
MarineCommander™

Chart Plotter Wiring Diagram



* When the MXG-5000 GPS receiver is connected to the MXP-5000 through the MA-500TR or MXA-5000, this GPS receiver is not required.

Icom Inc.