

SPECIFICATIONS

Dimensions: 303.2 (W) × 179.7 (D) × 78.2 (H) mm, 11.9 (W) × 7.5 (D) × 3.1 (H) inch (projections not included)

Weight: Approximately 1.2 kg, 2 lb 10 oz
(with six charger adapters / without power adapter)

Charging temperature range: 16°C ~ 40°C, 61°F ~ 104°F

Power supply requirement: 12 ~ 16 V DC or the specified power adapter

All stated specifications are subject to change without notice or obligation.

Icom, Icom Inc. and the Icom logo are registered trademarks of Icom Incorporated (Japan) in Japan, the United States, the United Kingdom, Germany, France, Spain, Russia, Australia, New Zealand, and/or other countries.

Icom Inc.

1-1-32 Kamiminami, Hirano-ku, Osaka 547-0003, Japan.

Feb. 2019

Count on us!

A7372D-1EX-2 Printed in Japan
© 2017–2019 Icom Inc.

ICOM INSTRUCTIONS

MULTI CHARGER

BC-214
BC-214N

Thank you for choosing this Icom product.
READ ALL INSTRUCTIONS carefully and completely before using this product.
The BC-214/BC-214N MULTI CHARGER was designed to charge Li-ion battery packs. The charger adapters of the BC-214 and BC-214N are not interchangeable. You must use the adapters that are compatible with the charger you are using.

PRECAUTIONS

⚠ **DANGER! NEVER** charge non-Icom Li-ion rechargeable batteries. Never charge or use an alkaline, dry cell, third-party, or counterfeit battery packs or charger adapter. Otherwise, a fire and/or explosion may occur.

⚠ **DANGER! KEEP** battery packs away from fire. Fire or heat may cause them to rupture or explode. Dispose of an used battery pack in accordance with local regulations.

⚠ **WARNING! NEVER** modify the charger and/or power adapter. This may cause a fire hazard or electric shock.

⚠ **WARNING! NEVER** use deteriorated battery packs. They could cause a fire.

⚠ **WARNING!** Occasionally observe the battery pack condition while charging. If any abnormal condition occurs, discontinue using the battery pack.

CAUTION: DO NOT charge the battery packs in areas with extremely high temperatures, such as near fires or stoves, inside a sun heated vehicle, or in direct sunlight. In such environments, the safety/protection circuit in the battery will activate, causing the battery to stop charging.

CAUTION: DO NOT insert the battery packs (with/without the transceiver) into the charger if it is wet or soiled. This could corrode the battery charger terminals or damage the charger. The charger is not waterproof.

CAUTION: DO NOT charge the battery packs during a lightning storm. It may result in an electric shock, cause a fire or damage the battery pack or transceiver. Always disconnect the power adapter before a storm.

CAUTION: DO NOT let metal, wire, and so on, touch any internal parts of the charger.

CAUTION: DO NOT charge the battery in conditions of extreme cold (under 16°C, 61°F), or extreme heat (over 40°C, 104°F).

The battery may heat up or rupture if charged out of the specified temperature range. Additionally, battery performance or battery life may be reduced.

CAUTION: DO NOT use the charger with the power adapter when it is covered by objects that impede heat dispersal.

USE Indoors ONLY! NEVER expose the charger and the power adapter to rain, snow or any liquids.

Always place the charger in a secure place to avoid inadvertent use by unauthorized person.

USE only specified accessories. Using third party or counterfeit may result in a fire hazard or electric shock.

KEEP the charger away from TV sets or radios to prevent interference.

MAKE SURE battery and charger contacts are always clean. Otherwise, battery packs may not be charged properly.

Be careful of the battery pack's temperature—when the battery pack is extremely cold, the charger cannot charge the pack.

When the charger is not in use, disconnect the power adapter from an AC outlet. The power adapter consumes power when connected to the AC outlet.

When the operating period becomes extremely short after full charging, the battery pack has reached the end of its life and a new battery pack must be purchased.

An appropriate desktop charger adapter must be purchased separately to charge different Icom battery packs.

NOTE: If your battery packs seem to have no capacity even after being fully charged, completely discharge them, then fully charge them again. If they still do not retain a charge (or very little), a new battery packs must be purchased.

FCC INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

ABOUT CE

CE Versions of the BC-214/BC-214N which have the "CE" symbol on the product comply with the essential requirements of the 2014/30/EU directive for Electromagnetic Compatibility and the 2001/95/EC directive for General Product Safety.

DISPOSAL



The crossed-out wheeled-bin symbol on your product, literature, or packaging reminds you that in the European Union, all electrical and electronic products, batteries, and accumulators (rechargeable batteries) must be taken to designated collection locations at the end of their working life. Do not dispose of these products as unsorted municipal waste. Dispose of them according to the laws in your area.

SUPPLIED ACCESSORY

Item	Quantity
• Power adapter.....	1
① A different type or no power adapter is supplied, depending on the charger version.	

Icom is not responsible for the destruction, damage to, or performance of any Icom or non-Icom equipment, if the malfunction is because of:

- Force majeure, including, but not limited to, fires, earthquakes, storms, floods, lightning, other natural disasters, disturbances, riots, war, or radioactive contamination.
- The use of Icom transceivers with any equipment that is not manufactured or approved by Icom.


HOW TO CHARGE

1. Connect the power adapter as shown below.
 - No status indicator lights up.
2. Insert a battery pack, with or without the transceiver, into a charging slot.
 - The status indicator for the slot lights green for 1 second, then lights orange.
3. When the status indicator changes to green, battery charging is completed.

CAUTION: The transceiver power **MUST** be turned OFF during charging, otherwise:

- The battery pack will not correctly charged.
- The battery life may be shortened.

The transceiver cannot be used, even while charging.



◇ STATUS INDICATOR

- Lights orange: While charging (When a battery pack is inserted, lights green for 1 second, then lights orange.)
- Lights green: Charging is completed
- Blinks orange and green alternatively:
There is a problem with the battery pack and/or the charger.

NOTE: When the indicator turns OFF even while a battery pack is inserted, the connection may be poor. Reinsert the battery pack.

- The protection circuit is activated (not a malfunction) when:
 - The battery pack temperature exceeds 45°C (113°F).
 - Remove and cool down the battery pack.
 - The battery pack is at the end of its working life.
 - When the indicator blinks within 1 hour from the start of the charging, charge the battery pack again. If the indicator still blinks orange and green alternatively, replace the battery pack with a brand new one.